



Important safety instructions and warnings

General safety information

Handling and maintenance of the board

Handling and maintenance of the charger

Handling and maintenance of the drive battery

Handling and maintenance of the remote control

Proper use of the jetboard

Qualifications of the riders

Accident prevention

Protection of the jetboard riders and other persons involved



To avoid personal injury and damage to material, read these safety instructions carefully. In addition, the user manual must be studied carefully. These safety instructions are no substitute for reading the user manual. All safety instructions, hazard instructions, warnings and dangerous goods instructions can be found in the user manual!

Read these important safety instructions!



Please read the user manual before installing and using this product. If you do not have it, contact your account manager. The user manual can be found at <https://lampuga.com/de/support>.

General safety information

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.



If you wear a pacemaker or other electromedical device, are pregnant, or have any health concerns about using the product, consult your doctor before using the product.



Never attempt to disassemble or open the product yourself, as this could cause a short circuit, fire or electric shock. If you experience any technical problems, please contact your account manager.



The product may only be opened or repaired by an authorized dealer or service center after consultation with your account manager. If parts of your product need to be replaced for any reason, including normal wear and tear or damage, please contact your account manager.



If the product has been dropped, damaged or exhibits unusual behavior, it must not be used any further.

Handling and maintenance of the board

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.



Improper use of the product can result in serious or fatal injuries.



Do not attempt to operate the board with a battery other than the one provided. Using other batteries could damage or destroy the board and pose a risk of danger. Using other batteries will void the approval and/or the warranty.



When using the product, always wear the prescribed protective equipment and observe local regulations for operation.



Before using the product for the first time, read the operating instructions and familiarize yourself with local conditions and regulations.



Do not clean the board with any detergent. Use only clean, clear fresh water or a damp cloth to clean.

Handling and maintenance of the charger

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.



Do not attempt to charge the drive battery with a charger other than the one provided. Using other chargers could damage or destroy the battery and pose a risk of danger. Using other chargers will invalidate the approval and/or the warranty.



Charge/operate the product according to the instructions in the user manual.



When unplugging the power cord or an accessory, grasp and pull on the plug, not the cord.



Never attempt to disassemble or open the charger as this may result in a life-threatening electric shock.



Unplug the charger before cleaning.












Do not clean the charger with any cleaning agent. Use only a clean, dry cloth to clean.

Read these important safety instructions!








Handling and maintenance of the battery

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.

-  The battery should always be stored dry, protected from sunlight and at temperatures between 10 °C and 25 °C.
-  If the battery is to be stored for a longer period of time, the optimal charge level is about 40-50 percent.
-  The full performance of a new battery is only achieved after it has been fully discharged/recharged two or three times.
-  To charge the drive battery, only use the approved charger supplied with your product.
-  Dispose of the battery in accordance with local regulations. Please recycle the battery if possible.
-  The battery may cause fire or chemical burns if handled improperly. Damaged batteries may explode.
-  The battery can cause chemical burns if handled improperly. Damaged batteries can explode.
-  Do not dispose of the battery in household waste or in fire as it may explode.
-  Do not clean the battery with any cleaning agent. Use only clean, clear fresh water and a damp cloth to clean it.

Handling and maintenance of the remote control


Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.

-  The remote control is powered by a rechargeable battery. This is permanently installed and cannot be replaced.
-  The full performance of a new battery is only achieved after it has been fully discharged/recharged two or three times.
-  Only charge the remote control with the charger provided.
-  The battery may cause fire or chemical burns if handled improperly. Damaged batteries may explode.
-  The battery can cause chemical burns if handled improperly. Damaged batteries can explode.
-  Do not throw the remote control into household waste or into fire as it may explode.
-  Do not clean the remote control with any detergent. Use only clean, clear fresh water and a damp cloth to clean it.

Read these important safety instructions!





Proper use of the jetboard

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.

-  Improper use can result in serious or even fatal injuries.
Read the owner's manual. Note the maximum load capacity of the board.





Qualifications of the riders

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.

-  Riders must be qualified to operate a jetboard.
-  Riders must be at least 16 years old and familiar with how to operate the jetboard.
-  Riders must be physically and mentally capable of operating the jetboard safely at all times.
-  Make sure you meet all legal requirements for using a jetboard. Your country (or region) may have additional requirements (e.g. driving license, courses, registration) that must be met.

Accident prevention

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.

-  Riders must avoid collisions and drive carefully at all times.
-  Riders must constantly look out for people, objects and other watercraft and keep enough distance to be able to stop in time.
-  Riders must adapt their speed to local conditions.
-  The jetboard may only be used between sunrise and sunset when visibility is good and weather conditions allow safe operation.

Read these important safety instructions!

Protection of the jetboard riders and other persons involved

Please read all of the following sections carefully. If you have any questions or concerns, please contact your account manager.



A fall can result in serious or fatal injuries.



All riders must wear shorts with neoprene (wet suit material) to prevent water from entering their body orifices when falling from behind. Failure to do so can result in serious injuries to the body orifices.



All riders must wear an approved personal floating device (PFD).



Wearing a helmet is possible. The advantages and disadvantages must be weighed up individually.



Make sure riders are in a stable position and are holding on. Riders can be thrown if there is unexpected acceleration or aggressive riding. Riders must avoid aggressive riding, abrupt turns or unexpected acceleration.



Do not accelerate when a person is coming on board or is in the rear area of the board.



Do not jump over wakes or waves as this may cause injuries to the back and neck area.



Do not approach other people, animals or boats to spray them with water.



Excessive, uncontrollable speeds must be avoided.



You must never drive under the influence of drugs, alcohol or other intoxicating substances.